

WINDOW REMOVAL INSTRUCTIONS

Supplies needed:

Methyl Hydrate - you can find this at Lordco

(if you can't find Methyl Hydrate, rubbing alcohol will also be effective)

Knife

1. First thing that you are going to want to do is remove the Trim Ring if you have one
2. From the outside spray Methyl Hydrate around your window where there is Butyl and Silicone; This will dissolve and loosen the adhesive properties.
3. Use a Knife to cut away at the Butyl and Silicone. For this step you will want to be very patient and just take your time. You should be able to gently pull out the window while cutting it away.
4. Go inside your boat; if you notice a little Butyl and Silicone are on the inside as well apply some more Methyl Hydrate and use your Knife again to cut away at it.

The window will eventually come off but the main thing to remember is to take your time and not to rush. Patience is the key to removing your windows and keeping them in great condition. Remember if you run into any problems at all feel free to give us a call here at AJR Marine Windows and we will be able to provide some assistance.

Phone# 604-944-1616

Toll Free# 1-866-944-1616

Email: sales@ajrmarinewindows.com